Keycard Entry System - Light Display



Yellow Light **Blinking**: The wrong card was used.

Yellow and Red Light is on: Card could not be read, the card was pulled out too fast, or the magnetic strip is broken.

Green and Red Lights are blinking alternately: The battery is empty.

Green and Red Lights are on at the same time: Lock must be reprogrammed.